1873 Siesta Lane
Green Bay, WI 54313

Maintenance on the Therma Gauge and Overfill Alert Gauge.

Possible Problems:

The Therma Gauge or Overfill Alert Gauge can fail in one of three ways.

- The calibration assembly on the outside of the tank can become weathered, unreadable, or broken.
- The connecting rods that extend into the tank can come apart or become damaged.
- The float that sits at the bottom of the gauge can come off or become saturated with product (leak).

Recommended Maintenance Procedures

- Once per month: Inspect the top of the unit once per month to ensure that the calibration is visible, readable, and unbroken. (these top pieces can be easily replaced without having to replace the whole gauge)
- Once every 6 months: Unthread the unit and carefully remove it from the tank. Be sure all rods are connected as one piece from the red indicator all the way down to the float. Also inspect the float for damage or leakage. To ensure proper working order, manually raise the float arm from empty to full to be sure that the red indicator freely moves up and down with the motion of the float rod.
- Once every year: If you are using the optional Audible Alarm, the battery must be replaced once per year. Also repeat the previous monthly and bi yearly actions above.

Any follow-up questions can be directed to Lee Geurts (920) 434-8860.

Lee Geurts
lee@ksentry.com
http://www.ksentry.com