


## The Therma Gauge—Type H



Part Number—  
 H-(size opening)-(tank depth)+(ext)-(list options)  
 Sample—H-2-48+12

### What it is:

Top mounted liquid level gauge that can measure from 6 inches to 144 inches in depth. Bushing size can be 2" or 1.5". Gauges are custom made in house to fit your tank. Can also accommodate for double walls and pipe risers. The Type H Gauge has a 2 piece bushing construction that allows you to aim your swing arm away from walls, corners, and other obstructions.

### Additional Options - Not included:

**Audible Alarm Accessory:** This add on feature can turn your mechanical gauge into an audible Hi or Lo level alarm.

**LED At-A-Glance Accessory:** Another add on feature. This can give your mechanical gauge remote reading capability.

**Gauge Guard:** A cover that protects the exposed plastic components on top of the gauge.

### Replacement Parts -

**H-Kit** - Replaces all of the gauge components from the red lock nut and up. Includes: Red HDPE Plastic Nut, Duro Nitrile Gasket, Plastic Cellulose acetate inner and outer calibration.

**HG-Kit-ALN** - Replaces all of the gauge components from the red lock nut and up with upgraded parts. Includes: Aluminum Lock Nut, Duro Nitrile Gasket, Plastic Cellulose acetate outer calibration, Glass inner calibration.

### Instructions for Operation:

This gauge is a simple volume reading tool. The top of the red indicator is an indication of your approximate fuel level in your tank. Once installed, you simply view the calibration to monitor your tank level. Indicator is calibrated in eighths of a tank on one side, and quarters of a tank on the other.

Krueger Sentry Gauge  
 1873 Siesta Lane  
 Green Bay, WI 54313

www.ksentry.com



Contact us for more info:  
 Ph: 920-434-8860  
 Fax: 920-434-8897

Email: info@ksentry.com