



KRUEGER SENTRY GAUGE®

Gauge Guard



PVC Guard

Or Aluminum Guard

What it is:

The Gauge Guard is an accessory that retrofits to nearly all Krueger Gauges. It is a sleeve that slides over the exposed external plastic components of the gauge. Once installed, the guard will increase your gauges resistance to physical damage, weather, sun, and internal tank pressure.

Options:

The Gauge Guard is available in two different durable materials.

Select from either:

- PVC
- Aluminum



Examples of gauge guard in use.

Installation Instructions -

1. Unthread and remove the red nut (or in some cases it is aluminum).
2. Slip the guard over the gauge calibration and tight the gauge guards built in nut down to your bushing.
3. Before guard is fully tightened, be sure you can see your gauges red indicator through one of the gauge guards windows.
4. Finish tightening the guard until the calibration can no longer spin inside the guard.

Krueger Sentry Gauge
1873 Siesta Lane
Green Bay, WI 54313

www.ksentry.com



Contact us for more info:
Ph: 920-434-8860
Fax: 920-434-8897

Email: info@ksentry.com