KRUEGER SENTRY GAUGE
1873 SIESTA LANE GREEN BAY, WI 54313 | 920-434-8860 | www.ksentry.com

Gauge Guard

The Gauge Guard is an accessory that retrofits to nearly all Krueger Gauges. It is a sleeve that slides over the exposed external plastic components of the gauge. Once installed, the guard will increase your gauges resistance to physical damage, weather, sun, and internal tank pressure.



Example of gauge guard in use

(Gauge not included)

Installation Instructions

1. Unthread and remove the red nut (or in some cases it is aluminum).
2. Slip the guard over the gauge calibration and tight the gauge guards built in nut down to your bushing.
3. Before guard is fully tightened, be sure you can see your gauges red indicator through one of the gauge guard windows.
4. Finish tightening the guard until the calibration can no longer spin inside the guard.

Options:

The Gauge Guard is available in two different durable materials. Select from either:

- PVC
- Aluminum

PVC Guard



Aluminum Guard

