User Guide Electronic Gauge

Congratulations on your purchase of the LED at a glance.

Product Features include:

1. **Tank Level Check:** One button push will register current tank level.
2. **Alarm Test:** Two button pushes will test sounder with one chirp.
3. **Fill Mode:** Three button pushes will register current tank level and update level while filling. LED's will stay lit for five minutes. Alarm will start chirping slowly at 7/8 of a tank then very rapidly when full. Push again to exit fill mode.
4. **Battery Check:** Four button pushes will display remaining current battery power level. (Battery levels below 2 will cause the sounder to chirp and the fault light to light during level check.)
5. **Alarm Setting:** Five button pushes will light the LED corresponding to the current alarm setting. If alarm is in the off mode no LED will light. In the battery well there are three switches. The switch to the left will turn the alarm on (up) or off (down). See below for switch settings. When desired setting/level is reached the alarm will chirp every minute for one hour then once every hour. When the button is pressed the alarm will be silent for 24 hrs and then start chirping again ……

Alarm Switch Settings





KRUEGER SENTRY GAUGE CO. INC.
Phone (920) 434-8860 Fax (920) 434-8897